

# Class II. cavity preparation

Defects affecting one or both proximal surfaces of posterior teeth.



# Symptoms

- No symptoms
- Increased sensitivity (cold, sweet)
- Retention of food
- Defect (carious lesion is open – the enamel is broken)
- Bite sensitivity (when carious lesion is open)

# Diagnosis




- Visual changes of tooth structure
- Transillumination
- Radiography







4 stupňo  
grading



KTG vyseurem – Dite wing


# Preparation - amalgam

- Conventional preparation acc. to the Black's rules
- Slot preparation
- Large preparation – cusp(s) involved

# Preparation - adhesive materials

- Conventional preparation for composites
- Adhesive slot
- Tunnel preparation


# Conventional preparation



Occlusal cavity

Proximal cavity - box

Isthmus



Axial wall

Gingival wall

Pulpal walls


# Access to the cavity

From the occlusal surface

Through the undermined enamel


Separation using wooden wedges is useful


Pre op





## Access to the cavity





- Skalpel
- Kauter
- Laser
- Temporary filling



# Cavity border and extention for prevention

## Proximal box:


Axial wedges


Under the free gingiva

## Occlusal

Class I. cavity preparation


## American rule






# Retention


- Occlusal cavity – auxilliary cavity
- Undercuts
- Grooves



Autoretention




Grooves



# Resistance

- No undermined enamel
- No sharp wedges
- Isthmus is  $1/3 - 1/4$  intercuspidal distance
- Angle between axial and gingival wall:  $90^\circ$ , or  $85^\circ$
- Width of gingival wall is 1 mm at least
- Thickness of the filling 2 – 4 mm (4mm cusp replacing)



G. wall


Isthmus

$90^{\circ}$

Cavosurface angle

# Excavation of carious dentin

Rounded bur





(*Caries Detector, Kuraray,  
Japonsko; Caries Marker,  
VOCO, Německo*)


# Finishing of cavity walls

- Red coded diamond bur
- Chisel on the gingival wall (if in enamel)










# Cavity control

- Goog light, miror

Isthmus



Axial wall

Gingival wall

Pulpal wall

# Matrix placement

- Matrix primarily is used when a proximal surface is to be restored

The objectives:

- Provide proper contact
- Provide proper contour
- Confine the restorative material
- Reduce the amount of excess material


# Matrices



- Ivory I retainer Ivory 1
- Hawe Neos retainer Ivory 8
- Tofelmire matix and retainer

# Wedges

## ➤ Wooden wedges




- tighten the matrix band
- compress the gingiva
- separate the teeth






# Wedging

- Slip the matrix band over the tooth (apical to the gingiva margin – 0,5, - 1 mm)
- Tighten the matrix, check it with probe
- Place a wedge
- Turn the retainer  $\frac{1}{4}$  counterclockwise
- Contour the band









Trituration!

# Condensation of amalgam

- Condensor – stamen is the best one
- Power driven condensation

How big the stamen should be??
















???








# Base

- Zinkoxidphosphate cement
- Zinkoxidkarboxylate cement
- Glass ionomer cement
- Zinkoxideugenol

On pulpal walls only!


















The base must be hardened

# Amalgam

## Retention









# Instruments

- Preparation
- Filling
- Finishing and polishing

## Cpátko tyčinkové



## Ořezávač -Frahm






## Ořezávač - Sapin



## Ořezávač discoid-cleoid



Nosič amalgámu



