

Spotřebič	Notebook 1	Notebook 2
Příkon (kW)	0.065	0.075
Denní využití (min.)		
1.	235	95
2.	175	195
3.	340	215
4.	20	40
5.	205	40
6.	610	90
7.	640	65
8.	240	70
9.	255	85
10.	325	10
11.	165	155
12.	280	60
13.	285	70
14.	295	75
15.	120	85
16.	405	230
17.	400	220
18.	205	115
19.	235	95
20.	50	40
21.	570	70
22.	445	45
23.	25	95
24.	390	180
25.	665	35
26.	220	200
27.	320	80
28.	310	170
29.	105	95
Celkem hodin	143.3	51.6
Spotřeba (kWh)	9.3145	3.87
Celková spotřeba (kWh)		
Cena měsíční spotřeby (tarif D02d 4,80)	44.70	18.60
Celková cena		

Mikrovlňka	Lednice	Televize
1.45	0.09	0.065

5	Nonstop	65
10	Nonstop	125
5	Nonstop	10
30	Nonstop	65
35	Nonstop	10
5	Nonstop	25
40	Nonstop	35
15	Nonstop	60
15	Nonstop	60
20	Nonstop	60
5	Nonstop	140
30	Nonstop	70
40	Nonstop	65
10	Nonstop	100
25	Nonstop	105
5	Nonstop	90
5	Nonstop	75
10	Nonstop	90
5	Nonstop	70
25	Nonstop	35
25	Nonstop	20
40	Nonstop	70
60	Nonstop	20
5	Nonstop	25
10	Nonstop	20
5	Nonstop	35
5	Nonstop	65
10	Nonstop	40
15	Nonstop	60
8.58	696	29.6
12.441	62.64	1.9175
90.183		
59.70	300.70	9.20
432.90		

Cena za měsíční používání

- Notebook 1
- Notebook 2
- Mikrovlňka
- Lednice
- Televize



í jednotlivých spotřebičů

