




Optické metody


pokrač.


Turbidimetrie
Nefelometrie
Fluorimetrie
Luminometrie




















A010


Luminiscence


➤ Fotoluminiscence

- Fluorescence
- Fosforescence

➤ Chemiluminiscence








Fluorofory

Přirozené fluorofory

- Tryptofan
- porfyriny

Analytické fluorofory

- Fluorescein
- Methylumbelliferon
- Methylumbelliferonfosfát (MUP)
- Cheláty lanthanidů (Europium)




v.č. 2962615

I.

B P HOME BACK



1296-031 DELFIA® PLATE PUNCH

WALLAC



DELTA PLATE DISPENSE

ALLAC



HIM B42054300

v.č. 2962611

1296-061 DELFIA® DISKREMOVE

WALLAC

- VACUUM
- LEVEL
- POWER

HIM B42054301

HIM

1296-062 D... VACUUM UNIT

9.

9.

