

# CONWIP

(A pull alternative to kanban principle)

**Main resources** : Mark Spearman, David Woodruff and Wallace Hopp  
Northwestern University,  
Evanston, Illinois, USA

Diagrams, modifications, structures and editing (J.Skorkovský,KPH)

# Methodologies used for effective production control

- Based on **PULL** principle

- JIT

- Kanban (tool to support JIT)

- Zero inventory


- Kanban is used mostly for repetitive manufacturing)

- Based on **PUSH** principle


- MRP (MRP-II)

- Based on both principles (**push** and **pull**)

- CONWIP (Constant Work-In-Process)



greatly reduced inventory levels  
and production lead times




 =buffer

 =machine centre

# PUSH and PULL


- **PUSH** : production jobs (production orders) are scheduled (MRP and MRP-II)
  - often **not feasible plans** are generated and problems are often detected too late
  - used fixed lead times=LT (see next slide) do not depend on capacity utilization
  - Mind you, that **production is a random process** and estimation of LT is very pessimistic




- **PULL** : production jobs (production orders) starts are triggered by completion of another job.
- **In the other words : It authorize releases of the jobs)**

# Flow time and Lead time


- **Flow time** (known also as a „**Cycle time**“)



- **Lead time** (constant used for planning)




# KANBAN




The number of cards in the system determines the WIP levels in the plant

# KANBAN



# One Card Kanban



A = input raw material

B = semiproduct

# Trade-offs

- Too many Kanban cards-> Too much WIP and long Cycle times
- Too few Kanban cards->lower throughput and vulnerability to demand
- Little's law :  $\text{Cycle Time} = \text{WIP} / \text{Throughput}$ 
  - see basic explanation further ahead
  - more detailed explanation : [Factory Physics](#) (W.J.Hopp and M.L.Spearman)

# JIT


- Kanban is not JIT (JIT is a manufacturing philosophy)
- JIT encompasses :
  - Kanban (card system transferring signals)
  - total quality control (TQM) – e.g. scrap loss not tolerated....
  - setup time reduction
  - worker participation !!!!
  - lean production (low level of waste)
- Advantages of JIT philosophy :
  - reduced WIP (Work In Process)
  - shorter flow times (cycle times)
  - **lower production costs**
  - greater customer responsiveness
  - reduces setup times

# **PUSH** and **PULL** are not mutually exclusive approaches and other statements...

- **Push** and **Pull** can be combined
- MRP is considered to be more applicable than kanban
- MRP is in almost any discrete part production
- Kanban(JIT,**pull**) – superior results if applicable
- Kanban(JIT,**pull**) – is difficult to use if :
  - Jobs with short production runs
  - Significant setup times (numerically controlled machines)
  - Remarkable Scrap losses
  - Unpredictable fluctuation in demand

# PUSH and PULL and the types of the queueing networks

- **Push** : open queueing network
- **Pull** : closed queueing network
- **Push** : schedule **Throughput** and measure (observe) WIP





- **PULL** : setup WIP and measure (observe) Throughput

# Advantage of **PULL** over **PUSH** (home study not fo MPH-AOMA)

- **PUSH** : WIP and Throughput fluctuations – result in violation of the assumption, that CycleTimes (**CT**) and therefore Lead Times (**LT**) are constant !
- WIP is easier to optimize than Throughput (**T**)
- **Little's law** :  
**Average CT = Average WIP / Average T** – meaning that **CT** cannot be constant but vary with **WIP** and **T**.
- **Pull is easy to manage** : why ? -> **WIP** is easier to control than **capacities** needed to appropriately release work in **push** system . The problem is estimation of these capacities as exact as possible,

# Little's Law (home study- not for MPH\_AOMA)

WIP	CT	TH
1	8	0,125
2	8	0,250
3	8	0,375
4	8	0,500
5	10	0,500
6	12	0,500
7	14	0,500
8	16	0,500
9	18	0,500
10	20	0,500
11	22	0,500
12	24	0,500



# CONstant Work In Process = CONWIP

- System having benefits of a PULL and can be used in variety of manufacturing environment
- CONWIP : generalized form of Kanban
- CONWIP relies on signals (electronic, paper cards...)

# CONstant Work In Process = CONWIP

- **Kanban:** card is used to signal production of a specific part
- **CONWIP :** card is assigned to production line and are not part number specific

# CONWIP Configuration

Basic CONWIP



Multi-Loop CONWIP




Kanban




# CONWIP

cards



BOM of the final product (7)



Container A

**Baglog list**

1 : 6 pc
2 : 6 pc
3 : 8 pc
4 : 8 pc
<b>6 : 0 pc</b>
<b>5 : 0 pc</b>
<b>7 : 0 pc</b>

SET=8:00

Container A

**Baglog list**

1 : 6 pc
2 : 6 pc
3 : 0 pc
4 : 0 pc
<b>6 : 4 pc</b>
<b>5 : 0 pc</b>
<b>7 : 0 pc</b>

SET=10:00

Container A

**Baglog list**

1 : 0 pc
2 : 0 pc
3 : 0 pc
4 : 0 pc
<b>6 : 4 pc</b>
<b>5 : 2 ks</b>
<b>7 : 0 ks</b>

SET=12:00

Container A

**Baglog list**

1 : 0 pc
2 : 0 pc
3 : 0 pc
4 : 0 pc
<b>6 : 0 pc</b>
<b>5 : 0 ks</b>
<b>7 : 1 ks</b>

SET=14:00

System Entry Time=SET

maintaining of BLL is responsibility of inventory control staff

# CONWIP parameters (home study- not for MPH\_AOMA)

- The card count (it determines the max WIP level for the line) =m
- Production quota (target production quantity/period) =q
- Maximum work ahead amount =n (if q+n is produced during a period, the line is stopped until the start of the next period)

# CONWIP-air traffic control



Originating airport



Destination airport  
(air above airport)

If heavy air traffic, departing planes should be held on the ground at the originating airport rather than control flying aircrafts in the air above destination airport as a holding pattern

**The results : greater safety and lower fuel consumption**

# CONWIP-Theory of Constraints

- Balance the flow and not the capacity
- Operation of the CONWIP line is regulated by the bottleneck resource
- If we have sufficient demand, the correct number of the cards will maintain just enough WIP to keep bottleneck busy

# Thanks for your attention

(next few slides are not part of this course )

## Utilization, Bottleneck rate and Raw process time (cycle time)

- **Arrival rate to the machine** (working centre) = AR
- **Effective Production Rate** (maximum average rate at which workstation can process parts, considering effects of failures, setups and other detractors that are relevant over the planning period) =EPR
- **Utilization = AR/EPR = U**
- $r_b$  = *parts per time unit of the workstation with highest long-term utilization (U)*
- $T_0$  = raw process time of the line =  $\sum_1^N PT_i$  ,where N= number of workstations
- **Critical WIP** =  $W_0 = r_b \times T_0$  ,where  $T_0$  =minimum cycle time and  $r_b$  = maximum throughput

# Example

- Capacity of 4 machines is equal
- Thus every machine is bottleneck
- Line is balanced
- $r_b = 0,5$  product/hour
- Daily line produces 12 products =  $0,5 \times 24$
- $T_0 = 8$  hours = 2 hours (product on one machine)  $\times$  4 machines in the line
- **Critical WIP**  $= W_0 = r_b \times T_0 = 0,5 \times 8 = 4$  product
- S





# Little's Law

- $WIP = TH \times CT$ , where TH=throughput and CT=cycle time

# Little's Law

WIP	CT	TH
1	8	0,125
2	8	0,250
3	8	0,375
4	8	0,500
5	10	0,500
6	12	0,500
7	14	0,500
8	16	0,500
9	18	0,500
10	20	0,500
11	22	0,500
12	24	0,500



# Conwip

